

Installation Steps

Tools for the installation: An allen wrench size 6mm and a jaw wrench SW22

For all pipes with diameters Ø10 to 42mm, 3/8" to 2" Tube (external Ø), and 1/4" to 3" pipe (internal Ø).

serv-Clip 1

for mounting on pressurized pipes



place of installation



screw down
clamp bolts



remove paint



plunge the needle



clean pipe



ready to measure



clamp SC onto
pipe

serv-Clip 2

for mounting on non-pressurized pipes



place of installation



plunge the needle



remove paint and
clean pipe



remove stirrup
and needle



clamp SC onto
pipe



screw valve



screw down
clamp bolts



ready to measure